



Use 2mm allen key to secure three of joints. The arm will be fixed when car is moving. But you can't secure them with screw to bottom very tightly, otherwsie, the internal mechanism will be destroyed.

